



LNG Carrier Model - Operations Manual

G-Sim

Liquid Gas Handling Simulator (LGHS)



ID: GSim-LNGOM-01

Date: July 2017

Copyright © 2017 GTT Training Ltd. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, by photocopying, recording, or otherwise, without the prior written permission of GTT Training Ltd. Information furnished by GTT Training Ltd is believed to be accurate and reliable; however, no responsibility is assumed by GTT Training Ltd, for its use; nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent rights of GTT Training Ltd.



Contents

Introduction	5
Model Description	5
Model configuration	5
To define a new model configuration.....	6
To add additional definitions	7
Configuration Options Available	7
Displays	9
Navigation	9
Graphics Displays	9
Instructor Panels	10
Specific operating features	11
Cargo Pumps	11
To operate the pumps in manual mode:	11
To operate pumps in automatic mode:	11
Spray Pumps.....	13
To operate the spray pump in manual mode:	13
To operate pumps in automatic mode:	13
HD Cargo Compressors	15
To operate H/D compressors in Manual mode:	15
To operate H/D compressors in Automatic Mode:.....	15
To stop H/D compressor:	15
To operate Nitrogen Seal Supply in Automatic Mode:	16
LD Compressors	17
Single Stage LD Compressors	17
Two stage LD Compressors	20
Cargo Heater(s)	40
Heater Operation	40
Vaporisers	41
Vaporiser Operation	41
Fixed Gas Detection System.....	42
Gas Detector Operation	42
Portable Gas Detection	44



Instruments provided:	44
Operating Procedures:	44
Inert Gas Generator	46
Operating procedure.....	46
Nitrogen Generator.....	47
Operating procedure.....	47
Supply to Pressurisation Header & Insulation Spaces	47
To operate the Nitrogen purging of the Insulation or Interbarrier spaces:.....	48
Emergency Shutdown System.....	49
Loading Rate Control.....	50
Control of loading / liquid flow rates	50
Control of vapour flow rate	51
To select LNG or N2 supply	52
Berth Control.....	54
Normal Mode	54
Connected Mode	54
Tank Contents Control	56
Cargo Tanks.....	56
Ballast Tanks.....	58
Fuel & FW Tanks.....	59
Alarms	60
Listing of Graphics Displays.....	67
Process Overview	67
Status	67
Emergency Shutdown	68
Operation Mimics	69
Gas Detection.....	70
Fixed Gas Detection	70
Portable Gas Detection	71
Cargo Pipelines.....	72
Cargo Pipelines.....	72
Manifold.....	73
Machinery Room.....	74
Cargo Tanks.....	75



Cargo Tank No.1 (2,3,4)	75
Temperature No.1 (2,3 4)	76
Glycol System	77
Compressors	78
HD Compressors.....	78
LD Compressors	79
Lub Oil System.....	80
Heaters	81
Heaters.....	81
LNG Vaporiser	82
Forcing Vaporiser	83
Steam System.....	84
Nitrogen	85
Nitrogen Generator.....	85
Nitrogen Distribution	86
Inert Gas.....	87
Inert Gas.....	87
Engine Room	88
Engine Room	88
Ballast.....	89
Ballast System	89
Aux Tanks	90
Ancillary Tanks	90

Introduction

G-Sim provides the capability for training to be conducted using various system or ship models. This operations manual describes the details and capabilities of the LNG Carrier ship model along with how the various aspects of the specific model should be operated and controlled.

For details regarding the operation of the main G-Sim platform and the user interface reference should be made to the '**G-Sim Operations Manual**'.

Model Description

The purpose of the LNG Carrier model is to provide the training provider or instructor with the capability to configure the ship to be the most suitable for use in the training session to be undertaken. The LNG Carrier model comprises all the systems that are installed on board the real vessel(s) associated with the cargo, and ballast, enabling the simulation of any operation related to the management of the cargo and stability that may be conducted on this type of vessel. The controls for the equipment and systems are designed to be as close to the controls that will be found on board the actual vessels as possible taking into account the different user interface.

The model is displayed to the operator via a set of graphical displays, each depicting a particular system or item of equipment, together with all the information and control mechanisms that are required to conduct the necessary operations. In addition to the graphical displays, the instructor may also be provided with a set of supporting instructor displays to he/she to interact with specific aspects of the model both during exercises and for scenario development purposes.

For the general operation of the graphical displays and user interface reference should be made to the relevant section in the G-Sim Operations Manual.

The following describes the specific features and their operating requirements for the LNG Carrier model and the various configurations.

Model configuration

Although there are many LNG Carriers, with different types of tank and various sizes, many of the design features are common including:

- Tank arrangement
- Pipeline arrangements
- Equipment
- Operations that are conducted

The main change that has taken place on LNG Carriers since 2001 has been in the propulsion systems used on the vessels and the consequent changes in the way the boil off gas is handled. This has resulted in changes primarily to the equipment and arrangements within the machinery rooms, whilst most of the other arrangements are the same. Therefore, whilst the main training content will be similar, it may be necessary to use a different configuration of vessel to suit those being operated by a particular client, or to replicate a particular type of vessel to ensure the training delivered will be at its most effective.

The G-Sim LNG model has been designed to provide the operator with the flexibility to be able to select the configuration of the simulated 'vessel' that is to be used for the subsequent training session based on the following criteria:

- Vessel size
- Tank containment system
- Propulsion system
- Additional features

When installed, the software will be delivered with at least two configurations for the LNG Carrier model pre-defined. However, the operator may select other configurations as required using the Model Configuration utility as follows (a description is also available in the G-Sim Operations Manual).


Prior to starting the simulator, the model configurations that are to be available for selection by the instructor during the start process have to be defined. This may be done by using the 'Select Models' configuration tool which is accessed via the G-Sim Main Menu.



Up to 10 predefined model configurations may be defined. The above screen shot shows the situation with six configurations already defined with space for an addition four.

To define a new model configuration

- 1) Click on one of the numbers in the list which does not have a model defined against it (ie #7). A new list will be displaying showing the model groups which can be used for the new model definition.



- 2) Click on the appropriate group (eg LNG Carrier). This will open the option selection dialogue for the model group selected.

- 3) Enter the title to be used for the new configuration (eg 170 NO96 Steam)
- 4) Enter a description (if required)
- 5) Enter the file name to be used for the appropriate stability module for the size of vessel selected
- 6) Using the radio buttons, select the options that you wish to be included in the model (one from each category).
- 7) Select if any of the additional options are required by checking the appropriate checkbox, if applicable (these are optional)

The above picture shows a model configured as a 138,000m³, MarkIII containment, Steam propulsion using 2 x single stage LD compressors, fitted with a Regasification unit.

When you are happy with the choices, Click the 'Save' link.

This will return to the model list, showing the new model definition alongside the number previously selected.

The model definition is now available for use and when selected the appropriate graphics displays will be loaded accordingly.

To add additional definitions

- 1) Repeat the above process for the various models configurations that you may use.
Click 'Menu' to return to the Main Menu.

Configuration Options Available

The options available for selection by the operator for the LNG Carrier model are shown in the selection dialogue. As new options become available the displayed list will change to reflect the installed options. At the current time (May 2016), there are a minimum of twelve possible configurations for the model based on the following criteria:

- Vessel capacity: 138,000m³ or 170,000m³

- Containment system: GTT Mark III or GTT NO96
- Propulsion system: Steam or DFDE
- LD Compressor arrangement: 2 x single stage (steam only) or 2 x two stage (DFDE only)

Developments are currently in progress to add additional DFDE configurations, and a MEGI option which should be available in 2017.

When using the selection, if a selection is only applicable to one type of configuration, the other options will not be available

Displays

Navigation

Graphics Displays

Access to the various graphics displays is provided via a two level menu system, the higher level comprising the overall groups, and the lower level comprising the various systems within each group. Access between displays is also achieved via hot links allowing changing between displays without using the menu.

The actual displays within each group will be different depending upon the model configuration selected. However, the general format is as follows:

High Level Group	Lower Level Displays
Process Overview	Status
	ESD
	Pipeline displays for various operations
Gas Detection	Fixed detector
	Portable detectors
Cargo pipelines	Main pipelines
	Manifold
	Machinery room overview
Cargo tanks	Each cargo tank
	Temperature monitoring for each tank
	Glycol system
Compressors	HD Compressors
	LD Compressors
	Lub Oil
Heaters	Heaters
	Vaporisers
	Steam / heating medium
Nitrogen	Nitrogen supply
	Nitrogen distribution
Inert Gas	IG Generator
Engine Room	Engine room
Ballast	Ballast System
Auxiliary Tanks	Fuel & FW Tanks

Instructor Panels

The instructor is also provided with access to the following instructor displays

General	
	Load Control (Port Side)
	Load Control (Stbd Side)
	Global Parameters
	Cargo Tanks
	Ballast Tanks
	Fuel & FW Tanks
	IG & N2
	Gas Malfunctions
	Compressor Malfunctions
	Leaks
	Alarms
	Valves

Specific operating features


The following describes the operating procedures that need to be applied for specific items within the LNG model.

Cargo Pumps

There are two cargo pumps provided in each cargo tank. They are of the single stage, electric driven, centrifugal, submerged type and can be operated in either Manual or Automatic mode. The method of operation is as follows

To operate the pumps in manual mode:

- 1) Set 'Power' for the pump to 'ON' and indicator is illuminated
- 2) Check start available indicator is illuminated (based on power availability and liquid level)
- 3) Set discharge valve to approx. 10% - 15% open position (check cargo operations manual).
- 4) Set tank filling valve to 100% open
- 5) Start pump. Monitor pump amps
- 6) When pump running (amps steady), slowly open discharge valve and when discharge valve >30% open, begin to close in tank filling valve to control discharge rate.



To operate pumps in automatic mode:

When in automatic mode the pump start and discharge start routines are based on a sequence controller. Full details of each of the respective sequences can be found in the pump descriptions within the Cargo Operations Manual. A description of the general sequences are shown below:


To start first pump sequence:

- 1) Set pump to stand-by to activate power.
- 2) Check 'Available' indicator is lit (indicating sufficient power and liquid level is above minimum level).
- 3) Check pump discharge, tank filling and tank isolating valves are closed.
- 4) Set pump to 'Automatic Control'
- 5) Start 'Pump Start' sequence by clicking 'Start' button and activating via the control bar.
- 6) Appropriate valves will open to the set positions, pump will then start, and once running filling valve will adjust to maintain pump load at minimum setting (60%).

To start second pump sequence:

- 1) Once first pump is running follow steps 1 – 5 above for second pump. As filling valve is already open, pump will start immediately the discharge valve has opened to the required set position.

To start discharge sequence:



- 1) Check at least one cargo pump is running.
- 2) Check 'Discharge Sequence Available' indicator is lit (indicating at least one pump is running).
- 3) Activate discharge sequence by clicking 'Start' button and then the control bar.
- 4) The tank isolating valve will now begin to open and after a set time period, the filling valve will close.

To increase required motor load (capacity):


- 1) Check pump running and load equals set point (red bar).
- 2) Increase required load setting by placing cursor on '+' button and clicking on 'ON' on control bar. Setting will increase by 5% on each click.
- 3) To decrease required motor load setting place cursor on '-' button and click OFF on control bar. Setting will decrease by 5% on each click

To stop pump in automatic mode:

- 1) Click 'Start' button and then OFF on the control bar.

Spray Pumps

There is one spray pump provided in each cargo tank. They are of the two stage, electric driven, centrifugal, submerged type and can be operated in either Manual or Automatic mode.



To operate the spray pump in manual mode:

- 1) Set 'Power' for the pump to 'ON' and indicator is illuminated
- 2) Check start available indicator is illuminated (based on power availability and liquid level)
- 3) Set discharge valve to approx. 10% - 15% open position (check cargo operations manual).
- 4) Set spray return valve to 100% open
- 5) Start pump. Monitor pump amps
- 6) When pump running (amps steady), slowly open discharge valve and when discharge valve >30% open, begin to close in spray return valve to control discharge rate.

The positioning of the discharge and the spray return valves prior to starting the pump should be as indicated in the cargo operations manual.

To operate pumps in automatic mode:

When in automatic mode the pump start and discharge start routines are based on a sequence controller.

To start spray pump sequence:

- 1) Open spray header isolating valve on the respective tank.
- 2) Set pump 'Power On' to activate power.
- 3) Check 'Available' indicator is lit (indicating sufficient power and liquid level is above the minimum required).
- 4) Check pump discharge, and spray return valves are closed.
- 5) Start 'Pump Start' sequence by clicking ON button and activating via control bar.
- 6) Appropriate valves will open to set positions, pump will then start and once running the spray return valve will adjust position to maintain pump load at minimum setting (60%)

To increase required motor load:

- 1) Check pump running and load equals set point (red bar).
- 2) Increase the required load setting by placing cursor on '+' button, located to the right of the controller display, and clicking on 'ON' on control bar. Setting will increase by 5% on each click.
- 3) To decrease required motor load setting place cursor on '-' button, located to the right of the controller display, and click OFF on control bar. Setting will decrease by 5% on each click

To increase required spray header pressure:


- 1) Check pump running and load equals set point (red bar).
- 2) Increase the required pressure setting by placing cursor on '+' button, located to the left of the controller display, and clicking on 'ON' on control bar. Setting will increase by 10kPa on each click.
- 3) To decrease required pressure setting place cursor on '-' button, located to the left of the controller display, and click OFF on control bar. Setting will decrease by 10kPa on each click

To stop pump in automatic mode:

- 1) Click 'Start' button and then OFF on control bar.

HD Cargo Compressors

Two high duty (HD) compressors are provided. The H/D compressors are used for the movement of large volumes of vapour. The HD Compressors are single speed, with the capacity controlled by adjusting the vane angle in the compressor inlet. They can be operated in Manual or Automatic mode.



To operate H/D compressors in Manual mode:

Note: The compressors are always started and stopped manually. Automatic control is only applicable to the capacity control once the compressor is running.

- 1) Check N₂ supply is open from Engine Room, the supply valve to compressor is open and there is sufficient pressure at seal.
- 2) Check the lubricating oil supply and return to/from compressor are open and the lub oil pump running and alarms extinguished.
- 3) Set the discharge valve to 100% open position (may not open immediately as non – return valve).
- 4) Open the compressor inlet valve 100% and check the suction pressure is positive.
- 5) Check the vane angle is set to minimum using the vane angle set point control.
- 6) Set 'Power On' for the compressor to activate power.
- 7) Start the compressor by selecting 'Start' indicator and clicking right hand end of control bar. Confirm compressor starts and flow rate increases and then becomes steady
- 8) Once running, increase the compressor capacity by increasing the position of the vane angle. Locate the cursor over the vane control indicator and using the control bar select the required % open for the vanes. Once selected the actual vane angle will gradually move to the selected position.

To operate H/D compressors in Automatic Mode:

Once started the H/D compressors can be set so that the capacity will adjust automatically to maintain a set pressure within the vapour header.

- 1) Check the compressor running.
- 2) Set the required vapour header pressure that is to be maintained by locating the cursor on the red 'SP' column indicator to the left in the controller, and by using the control bar select the required pressure. The actual pressure selected will be displayed beneath the column and can be adjusted by selecting another position on the control bar.
- 3) When the required vapour pressure has been selected place compressor into automatic by selecting 'Automatic Control' indicator and then clicking on the control bar. Once in automatic model the vane angle will now adjust automatically dependent upon the actual vapour header pressure compared to the required set point.

To stop H/D compressor:

- 1) Select 'Start' indicator then OFF on control bar.

To operate Nitrogen Seal Supply in Automatic Mode:

The Nitrogen Seal Supply can also be set to operate in Automatic mode.

- 1) Set the required Nitrogen pressure for the compressor seal (usually > 30kPa). To do this locate the cursor on the green 'SP' bar located beneath the Automatic / Manual selection buttons, and then select the required pressure using the control bar. The actual pressure selected will be displayed to the right of the bar (PV).
- 2) When the required Nitrogen seal pressure has been entered place the supply valve into automatic by selecting either the 'Manual' buttons and the clicking OFF on the control bar. The supply valve will now adjust accordingly to maintain the pressure at or above the set point.

LD Compressors

Usually two LD Compressors are provided for use as part of the Fuel Gas supply system to the engine room. However, the type, design and operating requirements differ depending upon the propulsion system selected. The following describes the various types that can be incorporated into the LNG Carrier model:


Single Stage LD Compressors

Two single stage compressors are used when the steam propulsion system is selected. The single stage LD Compressors are variable speed, with the capacity controlled by adjustment of the vane angle in the compressor inlet, and motor speed. They can be operated in manual or automatic mode.

Capacity control:

- 0 – 50% Fixed motor speed, adjustment of vane angle, min to max position
- 50 – 100% Vane angle set to maximum, increase motor speed

The LD Compressors can only be operated individually (one main, one standby)



To operate L/D compressors in Manual mode:

- 1) Check N₂ supply is open from Engine Room, the supply valve to compressor is open and there is sufficient pressure at seal (see below).
- 2) Check the lubricating oil supply and return to/from compressor are open and the lub oil pump running and alarms extinguished.
- 3) Set the discharge valve to 100% open position (may not open immediately as non – return valve).
- 4) Open the compressor inlet valve 100% and check the suction pressure is positive.
- 5) Check the vane angle is set to minimum using the vane angle set point control.
- 6) Set 'Power On' for the compressor to activate power.
- 7) Start the compressor by selecting 'Start' indicator and clicking right hand end of control bar. Confirm compressor starts and flow rate increases and then becomes steady
- 8) Once running, increase the compressor capacity by:
 - a. Min – 50%
Increasing the position of the vane angle. Locate the cursor over the vane control indicator and using the control bar select the required % open for the vanes. Once selected the actual vane angle will gradually move to the selected position.
 - b. 50% - 100%
Increasing the motor speed (load). Locate the cursor on the 'SP' column and using the control bar select the required motor load (*Note: when compressor starts initial load setting is always 50%*).



To operate L/D compressors in Automatic Mode:

Once started the L/D compressors can be set so that the capacity will adjust automatically to maintain a set delivery rate to the engine room.

- 1) Check compressor running.
- 2) Set the required delivery rate to the engine room by locating the cursor on the 'SP' column alongside the 'Automatic Control' selection button, and using the control bar select the required pressure to be maintained in the vapour header. The actual pressure selected will be displayed beneath the column, and can be adjusted by selecting another position on the control bar.
- 3) When required delivery rate has been selected, place compressor into automatic by selecting 'Automatic Control' button and then ON on the control bar. The vane angle and motor load will now adjust automatically dependent upon actual vapour header pressure compared to the set point.

To stop L/D compressor:

- 1) Select RUN indicator then OFF on control bar.

To operate Nitrogen Seal Supply in Automatic Mode:

The Nitrogen Seal Supply can also be set to operate in Automatic mode.

- 1) Set the required Nitrogen pressure for the compressor seal (usually > 30kPa). To do this locate the cursor on the green 'SP' bar located beneath the Automatic / Manual selection buttons, and then select the

required pressure using the control bar. The actual pressure selected will be displayed to the right of the bar (PV).

- 2) When the required Nitrogen seal pressure has been entered place the supply valve into automatic by selecting either the 'Automatic or Manual' buttons and the clicking OFF on the control bar. The supply valve will now adjust accordingly to maintain the pressure at or above the set point.


Two stage LD Compressors

When the DFDE option is selected there are a number of possible configurations of LD Compressors that are in common use. Currently, within the LNG Carrier model the following options are selectable:


- Two, two stage LD compressors (version 1 – applicable to the standard LNG & 170k models)
- Two, two stage LD compressors (version 2 – applicable to the Asia Vision model)

For full details about the compressors see the LNG Carrier Cargo Operations Manual.

Version 1



Version 2



The prime differences between the two versions of compressor relate to the positioning of the pre and after coolers. The following descriptions explain the operating principles for each.

The following is applicable to both versions 1 & 2:

The LD Compressor forms part of the Fuel Gas Management System that regulates the flow of gas to the dual fuel engines. Consequently, once setup, its operation is usually in automatic mode. The following provides a description of the various controllers and the general operation of the compressors.

Control logic

All the process control elements (Valves, Compressor, compressor Diffuser Guide Valves, motor..) are manipulated by PID controllers. The basic target of the process control system has two functions

- 1) To manipulate the final control element in order to bring the process measurement to the set point whenever the set point is changed
- 2) To hold the process measurement at the set point by manipulating the final control element

The PID control algorithm does not “know” the correct output that will bring the process to the set point. Instead the PID algorithm continues to move the output in the direction that should move the process toward the set point until the process reaches the set point. So the PID controller must have a feedback (Process Variable “PV”), a set Point (SP) and an output Processing signal (OP) in order to perform.

A PID controller can work in three modes

- MAN: Operator manipulates the output of the controller directly, or a Program manipulates the output (P-MAN)
- AUTO: PID algorithm acts directly on the control element by processing the OP signal
- CASCADE: PID algorithm acts directly on the control element by processing the OP signal but in this case the SP of the controller is provided by second controller known as primary controller.

The secondary controller is in AUTO mode and Primary in CASCADE

During the process of starting-up all the controllers perform with all loops in manual. In the Plant the following indications are denoting the status of the controller.




Figure 1. Controllers in action (The letter M denotes the Manual mode, A the auto mode, and C the cascade mode)

In Man Mode, the SP value of the controller is equal to the PV value.

Controllers in the system

Tank Pressure Controller

The “Tank Pressure Controller” is responsible for maintaining the tank pressure at the required set point. It has two modes of operation 1) manual 2) auto.

In manual mode, output signal of the controller is not active (it is not controlling any element). In auto mode, the output signal of the controller is used to produce the Set Point of the flow controller.




Figure 2 Tank Pressure Controller (Tank pressure controller in M mode and AUTO mode).


The mode of the controller can be switched through the “Capacity Control Panel”, when AUTOMATIC CAPACITY is active, the controller performs in AUTO mode and in M mode under “MANUAL CONTROL”.

LD Flow Controller

The “LD Flow Controller” is responsible for controlling the compressor discharge flow. The output signal of the controller acts on

- 1) The diffuser Guide Vane of 1st stage
- 2) The diffuser Guide Vane of 2nd stage
- 3) Recycling compressors Valve

A simple schematic presentation of the OP actions is as follows:



Note: The output signal Flow controller is not acting directly on the DGVs (Diffuser Guide Vanes), but first the signal is corrected by 1) Motor load Controller 2) Isentropic Corrective Controller . These two controller have been modelled, but they are not visible on the graphics displays as no manual action is required for their operation.

It has three modes of operation 1) manual 2) auto 3) cascade mode




Figure 3 LD Flow Controller modes.

During the start-up, the controller is in manual mode. When the compressor's motor reaches full speed during the start up the controller becomes active.

Anti-Surge Controller

The "Anti-Surge Controller" is a pressure ratio controller. As it is a safety controller, it is activated only at extreme operating conditions under normal operation, its task is to keep the compressor from surging. Like the other controllers can work in Auto or MAN mode.




Figure 4 Anti-Surge Controller

The Anti-surge controller work in manual when compressor is not running or during the start up.

During, the start up the output signal of the controller on the Recycle valve is done P-MAN (a manual output controlled by a program). At all times, the output signal of the controller (PID loop) is compared with P-Man output before action. The Program Output (P-Man) differs between the FUEL/GCU modes.

- Under FUEL mode, the P-MAN is targeting to keep recycle valve open.
- Under GCU mode, the P-MAN is targeting to move RCV at a closed position as pre-cooling is not available under GCU mode.

As "anti-surge controller is safety controller" will override any signal from P-MAN when PV starts to get higher than SP.

FUEL Demand Controller

The "FUEL Demand Controller" is a Flow Indicator and Controller with the main purpose to

- 1) Adjust the flow to GCU
- 2) Correct the Set Point of LD Flow controller
- 3) increase/decrease burning capacity within the engines.

When Flow is higher than the demand the extra amount of BOG is diverted to GCU. The output of the “Fuel demand controller” is compared to the output of a Pressure indicator and controller¹. Both controllers can act on the “Flow diversion” mechanism, the signal of Pressure controller overrides the signal of the flow controller when there is risk of acute pressure drop which can lead to knocking/damage of the engines.

The “Flow diversion mechanism” acts on the Valve CG-615 and the request to DFDE engines for increasing/decreasing burning capacity.

When Valve CG-615 is under automatic control, the status of the Valve changes to “A” from “M”. During the GCU mode, the “FUEL Demand controller” remains under Manual mode at all times. Under the FUEL MODE, the “FUEL Demand controller” switches to AUTO mode when the delivery to Engines is started. The Delivery to engines is started after the activation of the “FULL SPEED mode”




Figure 5 Fuel Demand Controller

Operational Modes

The discharge pressure control mode of each LD compressor can be selected between fuel gas supply pressure control and GCU supply pressure control. Change between the two discharge pressure control modes is only possible during compressor stand still.



Figure 6 Control Panel for switching between Fuel/GCU mode.

Fuel gas supply pressure control

¹ The Pressure indicator and controller is not shown on the Graphics.

Under the fuel gas supply pressure control, the LD compressor (two-stage centrifugal compressor) will compress the BOG to maintain the fuel gas supply pressure at a constant level (6.5bara) by modulating the recycle valve and DGVs. In this mode, a BOG temperature at the compressor inlet between -140° and -120°C is required. The LD compressor gets started in the “50% Speed Mode” and it is locked to this speed. When the compressor has been running in low speed for more than 5 minutes with gas inlet temperature below -100°C, the high speed interlocked is removed. And operator activates the High speed mode. During, the low speed mode BOG is directed to GCU. With the activation of High speed mode and the discharge BOG at correct Temperature/Pressure, the delivery to DFDE engine is commenced.

GCU supply pressure control



If GCU supply pressure control is selected, the LD compressor is operated in 50% speed mode at all times. Pre-cooling is not required and no interlock exists on the inlet Temperature.

The Recycle valve remains open most of the time and capacity control is done though Diffuser Guide Vanes by the LD Flow Controller.

Version 1 - Operation procedures in GCU Mode -

Preparations of Compressors for condition “ready to start”

- 1) Prepare compressors auxiliaries
 - Align the supply of Lube- oil to the Skid
 - Align the supply of N2 sealing gas to the skid
- 2) For a successful start of the LD compressor, all the Permissives should be fulfilled. When the

required conditions for a permissive to be true are valid, the permissive is displayed as  otherwise displayed as .

In order the “Man Valves in position to be shown as TRUE, the discharge, suction, recycle and any block valve should be open.

Power permissive is ON given the compressor is at stby and sufficient power availability.



Figure 7. Compressor panel for Permissives.

- 3) Start the GCU plant
- 4) Align the Flow Path to GCU

Condition “ready to start”






Figure 8 Compressor Start Sequence Status

The compressor gets started through the activation of the START SEQUENCE. With the activation of the sequence the pre-lubrication will be started. The pre-lubrication takes two minutes to complete. The Indicator Pre-lubrication in Progress shows the status of the Pre-lubrication.



With the pre-lubrication in place the start signal to the motor will be given and the Running indicator under the control panel will become lit.



The controllers will continue to operate under the M mode till the compressor's motor reaches full speed. With reaching the desired speed at the 50% speed mode the compressors controllers will get active in AUTO mode.

The control logic will bring the recycle valve in closed position. With the RCV at closed position the operator can increase/decrease the set point of LD flow Controller.



Version 1 - Operation procedures in FUEL Mode

Select FUEL mode operation



Preparations of Compressors for condition “ready to start”

- 1) Prepare compressors auxiliaries
 - Align the supply of Lube- oil to the Skid
 - Align the supply of N2 sealing gas to the skid

2) For a successful start of the LD compressor, all the Permissives should be fulfilled. When the required conditions for a permissive to be true are valid, the permissive is displayed as  otherwise displayed as .

In order the “Man Valves in position to be shown as TRUE, the discharge, suction, recycle and any block valve should be open.

Power permissive is ON given the compressor is at stby and sufficient power availability.



Figure 9. Compressor panel for Permissives.

- 3) Start the DFDE /GCU plant
- 4) Align the Flow Path to GCU and DFDE

Condition “ready to start”






Figure 10 Compressor Start Sequence Status


The compressor gets started through the activation of the START SEQUENCE. With the activation of the sequence the pre-lubrication will be started. The pre-lubrication takes two minutes to complete. The Indicator Pre-lubrication in Progress shows the status of the Pre-lubrication.




With the pre-lubrication in place the start signal to the motor will be given and the Running indicator under the control panel will become lit.




The “running Up” indicator will start counting for the speed interlock release.



During the interlock time the activation indicator for full speed mode appears dark. When all the conditions are met, the activation indicator becomes green.



Then operator can start the BOG delivery to DFDE engines by switch to 100% speed.




Version 1 Detailed instructions - To Start LD Compressor


The compressor can be started in GCU or Fuel mode. GCU is straight forward it just goes to the GCU

Starting in Fuel mode


- 1) Start the spray pump to supply the pre-cooler, (suggested initial pressure approx 2 barg).
- 2) Note:
 - a) *the pre-cooler is required to maintain the inlet temperature into the LD Compressor <-120°C*
 - b) *Note the auto valve is only available in manual when the compressor is stopped and would be used for cooling the line down.*
- 3) Open the 2 valves to the engines CG617 & 618. Nothing will go to the engine as there is an invisible valve downstream that will only open when the pressure reaches 550kPa.



- 4) Open the valve to the GCU CG615 (this will also open automatically when the LD starts)
- 5) Open the cooling water to the heater cooler and the inlet and outlet valves.




- 6) Open the drain from the mist separator. This returns back to tank 3 or 4



- 7) On the compressor set up the lub oil and nitrogen as usual. Using number 1 for this example.
- 8) Using LD Compressor #1 as the example, open the surge isolation valve CG541 and discharge valves CG556 and CG562
- 9) Open compressor suction valve and CG704 from the vapour header.
- 10) Check permissives are all green



- 11) On the 'Start Up Mode' select 'Fuel mode'
- 12) On the 'Sequence Status' activate the Start Sequence. The progress of the start sequence is indicated by the yellow progress bars. Initially, the start sequence involves pre-lubrication which runs for 2mins.
- 13) When pre-lubrication is completed (progress bar = 100%) the compressor starts on 50% speed and the GCU valve (CG615) operation changes to automatic and opens (if not already open).
- 14) On starting the LD flow controller SP is automatically set at '1500' which is the minimum for the engines.
- 15) The start sequence will now continue with progress indicated on the lower progress bar. For a period of 5 mins the compressor is fixed at 50% speed. Note the recycle valve remains partially open at this time due to the low flow rate is so low the DGV are on minimum settings.
- 16) Once this period is over, speed increase to 100% is available indicated by the 'green >' indicator to the right of the 100% selection button.



- 17) The LD cannot increase to 100% speed until the inlet T has been less than -120(?) for 5 minutes.
- 18) Increase speed to 100% by selecting the 100% button. Discharge pressure from the compressor will now increase. When the pressure is 550 kPa the inlet valves to the engines open and the flow will increase. At the same time the GCU valve will close.

Running in manual

- 1) When the speed has been increased to 100% the setting for the LD flow controller can also be increased. This increases the flow through the compressor.
Note: The fuel demand is separate. If the fuel demand is still set to 1500 and the LD flow controller is set to 3000 then 1500 goes to the engine and 1500 to the GCU.
- 2) If the fuel demand exceeds the LD flow controller setting the LD flow controller SP changes to match the Fuel demand. i.e. if fuel demand and LD flow controller are at 1500 and the fuel demand is increased to 2000 the LD flow controller also increases to 2000.
- 3) If the Fuel demand controller is reduced the LD flow controller remains the same and the excess goes to the GCU unless the LD flow controller is brought down as well. The LD flow controller cannot be brought down less than the Fuel demand.

Running in Auto

- 1) When the capacity controller is in automatic the Tank pressure controller goes to Automatic mode and the LD flow controller is in cascade mode. The system tries to calculate the flow based on the tank pressure SP and the PV and adjusts the flow accordingly. If the Tank pressure controller SP is reduced the flow controller will increase the flow. It then calculates how quickly the tank pressure will fall in response to the flow so takes time to settle.


- 2) The tank pressure controller will set the LD flow control SP in order to achieve the tank pressure demanded. The fuel demand can be set independently and if the LD flow controller is greater than the fuel demand then the excess goes to the GCU. If the LD flow control set point is less than the fuel demand the Forcing vaporiser is started. This would be automatic on the real vessel but is manual on the simulator.

Version 2 - Operation procedures in GCU Mode –

Preparations of Compressors for condition “ready to start”



1) Prepare compressors auxiliaries

- Start the Lube- oil System, by turning ON the aux pump.



-Align the supply of N2 sealing gas to the skid, setting the required sealing Pressure above 30 kPa.


2) Prepare for “Permissives in place”.

For a successful start of the LD compressor, all the Permissives should be fulfilled. When the required conditions for a permissive to be true are valid, the permissive is displayed as  otherwise displayed as .

In order for the “Man Valves in position to be shown as TRUE, the following valves need to be open:


- Compressor discharge
- Compressor suction,
- Compressor recycle
- Any block valves related to the above

Power permissive is ON given the compressor is at “stby” and sufficient power availability.




3) Start the GCU plant

-Set Capacity Mode on MAN mode




-Set Capacity at 30%



- Align the supply of N2 sealing gas to the skid (valves:CN915, CN901)


- Align the BOG Flow Path to GCU to allow free flow of BOG through a BOG heater at a temperature of 20°C.

-Activate the Start Sequence of GCU by selecting the 'START' button




Condition "ready to start"


The compressor is started through the activation of the START SEQUENCE.




With the activation of the sequence the pre-lubrication will be started. The pre-lubrication takes two minutes to complete. The Indicator Pre-lubrication in Progress shows the status of the Pre-lubrication.



With the pre-lubrication in place the start signal to the motor will be given and the Running indicator under the control panel will become lit.




At the same, the Main Lub Oil pump will start automatically and Aux will stop.




The controllers will continue to operate under the M mode till the compressor's motor reaches full speed. When reaching the desired speed at the 50% speed mode, the compressors controllers will become active in AUTO mode.

The control logic will bring the recycle valve to the closed position.




With the RCV in the closed position the operator can increase/decrease the set point of LD flow Controller.



Version 2 - Operation procedures in FUEL Mode

Select FUEL mode operation



Preparations of Compressors for condition “ready to start”



1) Prepare compressors auxiliaries

- Start the Lube- oil System, by turning ON the aux pump.



-Align the supply of N2 sealing gas to the skid, set sealing Pressure to be above 30 kPa.

2) Prepare for “Permissives in place”.

For a successful start of the LD compressor, all the Permissives should be fulfilled. When the required conditions for a permissive to be true are valid, the permissive is displayed as  otherwise displayed as .

In order for the “Man Valves in position to be shown as TRUE, the following valves need to be open:

- Compressor discharge
- Compressor suction,
- Compressor recycle


- Any block valves related to the above

Power permissive is ON when the compressor is in “stby” and there is sufficient power availability.




3) Start the GCU plant

-Set Capacity Mode on MAN mode




-Set Capacity at 30%




- Align the supply of N2 sealing gas to the skid (valves:CN915, CN901)

- Align the BOG Flow Path to GCU for having free flow of BOG though a BOG heater at a temperature of 20°C.


-Activate the Start Sequence of GCU by pressing



-Align BOG Flow path DFDE Engines though BOG Cooler




-Start a Fuel Pump (in one of the cargo tanks)




-Start the cooling down of the Fuel header (by opening valve: CSi12, CS706, CS971,CS972 and condensate return valve


-After some time, align flow path though the LD pre-cooler.



For being able to supply LNG to pre-cooler set Pre-cooler TCV to manual mode. Then set LCV and TCV on Automatic.




-Align LNG supply to LNG in LINE cooler (by opening manual Valve) and set TCV on Auto




Condition “ready to start”


The compressor gets started though the activation of the START SEQUENCE



-Follow the pre-lubrication status of LD compressor, at the end of this phase the running phase in FUEL Mode will become active and Main Lub Oil Pump will take over.




-When RUNNING UP is elapsed, the compressor's motor is in FULL speed at 50%,




The indication for starting in 100% speed will become lit.

-Switch to 100% speed




-Adjust demand of Fuel controller as Required



Cargo Heater(s)

One or two main cargo heaters are provided depending upon the fuel gas management system arrangement that is implemented in the configuration selected. They are used for heating large volumes of vapour when warming up, or they may be also used as part of the fuel gas supply system.

The outlet temperature from the heaters can be maintained either in Manual or Automatic mode.



Heater Operation

To operate heaters in Manual Mode:

- 1) Open steam inlet and outlet valves.
- 2) Check steam supply is on (inlet pressure > 700kPa) and that steam outlet pressure from heater is > 100kPa.
- 3) Open the condensate drain valve
- 4) Open the inlet valves to heater (Note: Heater inlet valve will not open unless steps 1 & 2 have been completed due to a steam supply interlock)
- 5) Open the heater outlet valve.
- 6) Start the flow through heater and monitor outlet temperature. Outlet temperature can be adjusted by initially opening the temperature control valve (top) to reduce the outlet temperature. If this is insufficient the heater inlet valve should be closed in. The required outlet temperature is obtained and then maintained by adjusting both inlet valves together.


To operate heaters in Automatic Mode:

The 'Automatic' mode controller for the heater is designed to maintain an outlet temperature already set up, not achieve the setup from start (due to the wide temperature range). To place into automatic mode:

- 1) Carry out steps 1 – 6 above to obtain the required outlet temperature. (This should be done prior to placing into Automatic mode)
- 2) When the **required outlet temperature has been obtained**, select "Automatic Control" mode.
- 3) When Automatic Control mode has been selected the required temperature can be adjusted by selecting one of the three buttons located below the Automatic / Manual Control buttons. To maintain the temperature at either +80 or +25 select the appropriate button and then click 'ON' on the control bar.
- 4) To select a different temperature, select the 'Opr Select' button. When this is selected the current temperature of the outlet vapour is transferred to become the new set point for the automatic control. To change the temperature, place back into Manual Control, adjust the valves and when the correct temperature is achieved, place back into Automatic control.

For each of the above the temperature selected will now be displayed by the indicator and the inlet and temperature control valves will now adjust automatically to maintain the set temperature.

Two vaporisers are provided. The LNG Vaporiser has a large capacity and is used to produce large volumes of cargo vapour, or Nitrogen vapour. The smaller Forcing Vaporiser is used as part of the fuel gas supply system. Both vaporisers are operated in a similar way, with the outlet temperature capable of being maintained either in Manual or Automatic mode.



To operate the LNG or Forcing Vaporiser in Manual Mode:


- 1) Open steam inlet and outlet valves.
- 2) Check steam supply is on (inlet pressure > 700kPa) and that steam outlet pressure from heater is > 100kPa.
- 3) Open the condensate drain valve
- 4) Open the inlet valves to heater (Note: Heater inlet valve will not open unless steps 1 & 2 have been completed due to a steam supply interlock)
- 5) Open Vaporiser outlet valve.
- 6) Start flow of liquid to the vaporiser and monitor outlet temperature. The outlet temperature is controlled by adjusting the position of the temperature control valve (into heater outlet) to reduce the outlet temperature. If this is insufficient the flow rate into the vaporiser should be reduced. The required outlet temperature is obtained and then maintained by adjusting the position of the temperature control valve.

The 'Automatic' mode controller for the heater is designed to maintain an outlet temperature already set up, not achieve the setup from start (due to the wide temperature range). To place into automatic mode:

- 1) Carry out steps 1 – 6 above to obtain the required outlet temperature. (This should be done prior to placing into Automatic mode)
- 2) When the **required outlet temperature has been obtained**, select “Automatic Control” mode. When this is selected the current temperature of the outlet vapour is transferred to become the new set point for the automatic control. To change the temperature, place back into Manual Control, adjust the valves and when the correct temperature is achieved, place back into Automatic control.

Fixed Gas Detection System

The vessel is fitted with an automatic, sequential and constant hydrocarbon gas detection system for the cargo and engine room spaces. Details of the system can be found in the Cargo Operations Manual. Depending upon the space there are two alarm settings. If the gas level exceeds the 30% LEL alarm setting the alarm for the particular space will illuminate and remain on until the gas level has been checked to reduce below the alarm setting. Where the spaces are monitored constantly a 60% alarm is also provided which initiates various shutdowns if activated.



The system has three modes of operation:

- **Automatic**
Sequentially tests each sample point so that all points are tested at least once every 30 minutes as per IGC requirements
- **Manual**
This stops the auto sampling mechanism and allows the operator to select a particular sample point for testing by clicking on the orange sample point indicator. The gas level within that space will then be displayed until another sample point is selected.
- **Test**
Allows the instrument to be calibrated for zero using Nitrogen, for accurate reading using a 'Span' (test) gas or purged using Air.

Gas Detector Operation

To Operate in Automatic (normal) mode:

- 1) Place Gas Analyser to 'ON'
- 2) Start one of the sample pumps. If pump not started low flow alarm will be activated.
- 3) Select 'Automatic' mode.
- 4) Check orange indicator moves sequentially through the sample points.

To Operate in Manual mode:


- 1) Place Gas Analyser to 'ON'
- 2) Start one of the sample pumps. If pump not started low flow alarm will be activated.
- 3) Select 'Manual' mode
- 4) Select the required sample point to be tested by clicking on the orange sample point

To Operate in Test mode:

- 1) Place Gas Analyser to 'ON'
- 2) Start one of the sample pumps. If pump not started low flow alarm will be activated.
- 3) Select 'Test' mode
- 4) Open valve on 'Span' Gas supply. Check instrument reading
- 5) Close valve on 'Span' Gas supply.
- 6) Open valve on 'Zero' Gas supply. Check instrument reading
- 7) Close valve on 'Zero' Gas supply.
- 8) Select either 'Automatic' or 'Manual' mode.

Portable Gas Detection

The operator is provided with three portable gas instruments which may be operated, together with CO₂ and dewpoint readings which are provided automatically for the sample point selected. Located beneath the instruments are the sample points that may be monitored.



Instruments provided:

- Oxygen Meter
- Explosimeter (measures %LFL in air)
- Tankscope or Gas Meter (measures % volume in inert atmospheres)
- CO₂ (Carbon Dioxide) ppm
- Dewpoint (T in °C)

The method of operation of the instruments on the model has been set up so that the correct procedures have to be followed, as if using the real instruments. Readings are provided automatically on the CO₂ and Dewpoint instruments whenever the operator selects any of the other three instruments.

Operating Procedures:

Although instruments are of different types the operation of each is the same as follows:

- 1) Switch on instrument to be used. (If one instrument is already on it will automatically switch off if another chosen).
- 2) Purge instrument with air by locating cursor on AIR supply indicator and touching right hand end of control bar. Light will indicate as purging undertaken.
- 3) When AIR indicator extinguished, turn on span gas supply, located beneath the respective instrument.
- 4) Test instrument for correct span reading by operating 'SPAN' indicator.
- 5) Check reading corresponds with that expected.

- 6) Check 'ZERO' by first purging instrument with AIR (Explosimeter and Tankscope) or Nitrogen (Oxygen Meter). If not correct, locate cursor on 'ZERO' indicator and touch right hand end of control bar. Reading should change to 0.00.

Note: If ZERO indicator is operated whilst instrument is not being purged with the 'zero' calibration gas, there is the possibility that an error is introduced into the instrument. Consequently, 'ZERO' should only be operated after the correct zero gas has been purged through the instrument.

- 7) When calibration complete, re-purge instrument with AIR.
- 8) Locate cursor on required sample point and touch right hand end of control bar. Sample point chosen will light up and appropriate readings will be displayed on the actual instrument being used and on the CO₂ and dewpoint monitors.
- 9) Check readings.
- 10) PURGE instrument with AIR.


Note: The instrument has to be purged with air before a new sample point is chosen. If this operation is not undertaken the readings will not change.

- 11) Locate next sample point and check readings.

Note: The displayed reading indicates the amount of gas in the sample point at the time of the sample being taken. It will only change if another sample of the same space is undertaken.

Inert Gas Generator

A single Inert Gas Generator is provided which can be used to supply both Inert Gas and Dry Air.



Operating procedure

To operate in Dry Air mode:

- 1) Insert spool piece in SW supply line from ballast system
- 2) Line up and start ballast pump to supply SW to the IG Generator. Confirm Low Sea Water alarm is extinguished
- 3) Select 'Air' supply button
- 4) Select 'Power On' to activate power supply
- 5) Start Generator by selecting 'Start' button
- 6) The supply valves to the deck can be operated in manual or automatic mode.

To operate the valves in Manual mode select the 'Manual Control' button located beneath the valves and then click 'ON' on the control bar. The main supply, deck supply and vent valves can then be operated manually as required.

To operate the valves in Automatic mode select the 'Automatic Control' button. The main delivery valve to the deck will open once the dewpoint of the air is below the set point for the required. At the same time the vent valve will close.

To operate in IG mode:


- 1) Insert spool piece in SW supply line from ballast system
- 2) Line up and start ballast pump to supply SW to the IG Generator. Confirm Low Sea Water alarm is extinguished
- 3) Select 'IG' supply button
- 4) Select 'Power On' to activate power supply
- 5) Start Generator by selecting 'Start' button
- 6) The supply valves to the deck can be operated in manual or automatic mode.

To operate the valves in Manual mode select the 'Manual Control' button located beneath the valves and then click 'ON' on the control bar. The main supply, deck supply and vent valves can then be operated manually as required.

To operate the valves in Automatic mode select the 'Automatic Control' button. The main delivery valve to the deck will open when both the Oxygen and dewpoint levels are below the set values. At the same time the vent valve will close.

Nitrogen Generator

Two Nitrogen Generators are provided, together with a buffer supply tank. Details regarding the Nitrogen Generators can be located in the respective Cargo Operations Manual.




Operating procedure

- 1) Open the discharge valves from the generator and line up into the buffer tank
- 2) Select 'Power On' to activate power supply
- 3) Start the generator by selecting the 'On Line' button.

Once one of the Nitrogen Generators has been started, if the pressure within the buffer tank is below 300kPa, the generator will start running (shown by the running indicator) and the delivery valve into the buffer tank will adjust automatically to maintain the pressure within the buffer tank > 300kPa and below 800Kpa. Once the required pressure in the buffer tank has been achieved the 'Running' indicator will extinguish but the generator will remain 'OnLine' in standby mode. Only one generator is normally required to be operating but two will be required when cooldown operations in progress.

Supply to Pressurisation Header & Insulation Spaces


The nitrogen supply to the pressurisation header is controlled via a control valve. This valve is able to control the pressure in the pressurisation header to either 2kPa (normal mode) or 50kPa (cooldown mode). To maintain the correct pressure using the control valve:



- 1) Open the control valve inlet and outlet valves.

- 2) Select the required pressure button and then click 'ON' on the control bar. Valve position will now automatically adjust to maintain the required pressure in the supply header (PV value).
- 3) The control valve can be bypassed by opening the bypass valve.

To operate the Nitrogen purging of the Insulation or Interbarrier spaces:




- 1) Open the inlet and outlet valves for the appropriate control valve for the Insulation space or Interbarrier space N₂ supply.
- 2) Open the inlet and outlet valves for the appropriate control valve for the Insulation space or Interbarrier space N₂ exhaust (from vapour dome).

The control valves will operate automatically to maintain the defined pressure in each space and the correct differential pressure between the two spaces (see Cargo Operations Manual)

Emergency Shutdown System

The vessel is equipped with a sophisticated Emergency Shutdown System that can be activated by various conditions. Indication lights are provided which show the cause of the ESD if one should occur.



When alongside a terminal the vessels ESD system should be connected into the shore system using one of the methods provided (Optical Fibre, Pneumatic, Wireless) by selecting the relevant indicator.

To operate the system manually, select the yellow box located to the right of the ESD indicator which is displayed on most of the graphics pages, and then select 'ON' on the control bar.

The operator is also provided with the ability to disable the alarms and subsequent actions related to the Very High, and Extreme High level alarms.



When the appropriate 'Override' button is illuminated the effects of the alarm (shutting of the cargo tank filling valve or ESD activation) are disabled respectively.

Loading Rate Control

Using the appropriate 'Loading Control' instructor panel the instructor is able to set up the appropriate shore connections and control the flow rates in to and out of the vessel on all the manifolds.





Control of loading / liquid flow rates

When acting as the 'dummy jetty' (normal situation) the instructor can control the flow rates in and out of the trainee's vessel. This can be done line by line, or by entering a total value that the model then distributes across the lines that are open. Flow rates out of the model are controlled by the machinery being used within the model, but the instructor can alter the flow rate by increasing or decreasing the external pressure.

All flow rates within the model are dependent upon the pressure difference between the source and final destination. Consequently, a loading rate is controlled by gradually increasing the external supply pressure, which creates a pressure difference with the pressure within the lines in the vessel, causing a flow. To enable this increase to be linear a routine is used within the model.



To set the loading rates, perform the following steps:

- Check that students manifold valve is open. This can be seen by the current flow indicating non zero on the respective line.
- Check the shore valve for the respective line is open (can be seen via the graphical symbol on the page)
- Check the arm has been connected – indicated by 
- Check the blank on the respective line is not in place – indicated by 
- Set the 'Change increment' to be at a suitable value (usually 0.005 – 0.05). The change increment is the amount the actual shore pressure will increase or decrease every time step (0.5s) until the actual



pressure = required pressure. By changing this value, the speed of increase/decrease in flow can be controlled. (Note: a smaller value means the pressure will change more slowly causing 'hunting' but slower approach to the required value).

- f) Set the 'Maximum allowed' value > 1.00. The maximum allowed value indicates the maximum pressure to which the shore pressure will increase in absolute. Consequently, if the maximum value is set at 1.0 (0.0 gauge) this will be the same as the pressure within the model so there will not be any flow allowed. Usually the value should be set to a normal maximum line operating pressure (9.0 or 10.0) which will allow the line pressure to increase as required to maintain the requested flow.

- g) To set flow rate line by line:

- a. Change 'Set flow rate on separate manifolds to =  (Set total flow rate = 
- b. Enter a required flow in m3/hr for the appropriate line either by clicking on the value and entering a new value and clicking OK, or by clicking on the indicator bar and increasing the value using the control bar slider control
- c. Check external pressure on the line begins to increase
- d. Check actual flow on the line begins to increase and is inward flowing (Flow direction = 1)
- e. When actual flow = required flow check shore pressure remain stable
- f. To change flow rate, enter new required flow
- g. Repeat on the remaining lines

- h) To set a total flow rate:


- a. Change 'Set total flow rate =  (Set flow rate on separate manifolds = 
- b. Enter the required 'total' maximum flow rate (all lines combined) either by clicking on the value and entering a new value and clicking OK, or by clicking on the indicator bar and increasing the value using the control bar slider control
- c. Check external pressure on the lines begins to increase (Model calculates the required flow on each line to achieve the total dependent on the back pressure within the line so different flow rates may apply to different lines)
- d. Check actual flow on all the lines begins to increase and is inward flowing (Flow direction = 1)
- e. When actual flow = required flow check shore pressure remain stable

Control of vapour flow rate

Flow through the vapour manifold is determined purely by the pressure difference between the internal pressure, either directly from the vapour header or via the compressors, and the external vapour manifold pressure. When the manifold is being used as a vapour return to the shore there is no need to change the default external pressure setting.

To simulator shore gas return during a discharge operation:

- a. Locate the cursor on the external pressure applicable to the vapour manifold (center)




- b. Enter an external pressure between 1.000 & 1.300 bar.
- c. As the value is entered monitor the gas flow rate into the vessel. To maintain the pressures within the vapour header steady the inflow should be slightly higher than the liquid outflow.

To select LNG or N2 supply

At times it is necessary to change the liquid or gas that is in the external node (shore) for supply into the vessel. Depending upon the vessel configuration selected the operator can select between:

- LNG (default)
- N2 vapour
- N2 liquid



To change from LNG to N2 vapour click on the 'Shore Nitrogen? Symbol and change to = 

To purge the lines with N2:

- Select N2 supply as above
- Set manifold valves in correct positions (closed)
- Set flow rate control to be on individual manifolds
- Set 'Maximum allowed' parameter = 5.000 bar (4 bar / 400kPa gauge)

- Set required flow rate for the connection to be purged > 0 (usually 100). Check external pressure will begin to increase, and actual flow remains at 0 (If flow rate > 0 check valves are closed)
- When external pressure = maximum allowed (5.00 bar) open manifold valves. External pressure will now decrease.
- Repeat until line clear of methane.

Berth Control

The model is capable of being used in two modes:

- Normal mode – where the instructor acts as the jetty operator and the model is linked to a ‘dummy berth’ (this is the normal mode)
- Connected mode – where two models are connected directly together to enable the transfer of cargo from one model to the other (one station to the other). This mode is used when wishing to simulate direct ship to ship operations



Normal Mode

The screen shot above shows the model in ‘Normal’ Mode. To set the model in this mode:

- 1) Open the ‘Global Parameters’ instructor panel
- 2) Set the ‘BERTH’ parameter = -1
- 3) Set the ‘Side Moored’ parameter to = ‘P’ or ‘S’ depending upon the side you wish to be connected

Connected Mode

To connect two models together

- 1) Load the required scenarios into the two stations to be used (e.g. loaded on one, empty on the other)
- 2) Open the ‘Global Parameters’ instructor panel.
- 3) Set the berth number = a number between 1 and 5 (numbers larger than 5 are ignored). The number needs to be the same on both stations (ie if you decide to use #1, enter ‘1’ into both models)

Notes:

- a) The number you enter indicates a ‘berth’ number on the interface, not a station number. So on any station you should enter a number between 1 & 5.
 - b) The number has to be the same in both the models that you are linking. ie if you wish to use berth 1, you enter ‘1’ into both models indicating they are connected via interface No.1
- 4) You then decide which of the models is going to be the master (usually the one discharging) and which is the slave. For the master you set the ‘Interface Side’ = 2 and on the slave set it = 1
 - 5) You then set the connection arrangements by assigning the ‘Conn Flag’ or Connection No. to a value between 1 & 4 where:-

1 = P/S

2 = P/P

3 = S/P

4 = S/S

- 6) The 'Side Moored' parameter is not used when using the connected interface. It is only used along with the dummy berth (ie Berth = -1) when the instructor operates as the jetty.
- 7) When the above has been completed on both models you have to set the connection flags for the lines to be used on the appropriate side as you defined in (e) = T.

The models should now be linked and cargo will transfer from one to the other in the normal way.

Tank Contents Control

Cargo Tanks

The contents within the cargo tanks can be adjusted by the instructor via the 'Cargo Tanks' instructor display



Basic operation of the display is described within the G-Sim Operations Manual. Specific items relating to the cargo are described below:

1) Liquid Level

The liquid level is shown as a % full, and a sounding (in m) for each tank. To adjust the level select either the slider control and adjust as required or input a new % full. The sounding will adjust accordingly when the model is next run.

Note: Before the level in the tank can be adjusted there must be liquid present (ie a level already existing) in the tank concerned.

2) Two vapour phases

This indicates if there are two different vapours present in the vapour phase within the tank space. For example, if there is one gas already within the tank and another is introduced, this indicator will show if the gases are mixing (one mixed vapour) or separating (two vapour phases). This can be used to provide a quick indication as to whether inerting and gassing up operations are being conducted correctly (two vapour phase should = true)

3) Vapour phase properties

Information showing the current temperature, pressure, molecular weight and density of the current vapour phase

- 4) Liquid phase properties
- 5) Information showing the current temperature, pressure, molecular weight and density of the current liquid phase together with the makeup of the current composition of the liquid. The composition can comprise of:
 - a. IG
 - b. H₂O
 - c. CH₄ (methane)
 - d. C₂H₆ (Ethane)
 - e. C₃H₈ (Propane)
 - f. O₂
 - g. CO₂

The composition will be dependent upon the liquid loaded into the vessel from the external node and the temperature and pressure within the tank.

Note: The composition cannot be changed directly via this display. To change the composition please refer to the separate section in the Operations Manual.

Ballast Tanks

Instructor Page Portal

GENERAL

Load Control Port

Load Control Subd

Global Parameters

Cargo Tanks

Ballast Tanks

Fuel & FW Tanks

IGN2

Gas Instruments

Gas Malfunctions

Compressor Malfunction

Leaks

Alarms

Valves

DIAGNOSTIC

Node Data

P/T Points

Flow Regulators

Valve Properties

Connectivity

LNGTest

SC Node Data

SC Flow Regulators

BALLAST TANKS

Ballast Tanks	Altitude	Density	Liquid level (%)	Sounding	Malfunction Sounding	Malfunction Active
Port Peak	10.58	1,026.69	0.000	0.000	0.000	
Forward Port	-10.71	1,026.69	0.000	0.000	0.000	
No.1 Port	-10.74	1,026.69	0.290	5.463	0.000	
No.2 Port	-10.80	1,026.69	0.000	0.000	0.000	
No.3 Port	-10.85	1,026.69	0.000	0.000	0.000	
No.4 Port	-10.91	1,026.69	0.093	0.798	0.000	
Eng Rm Port	9.04	1,026.69	0.000	0.000	0.000	
Forward Stbd	-10.69	1,026.69	0.000	0.000	0.000	
No.1 Stbd	-10.73	1,026.69	0.290	5.463	0.000	
No.2 Stbd	-10.78	1,026.69	0.000	0.000	0.000	
No.3 Stbd	-10.84	1,026.69	0.000	0.000	0.000	
No.4 Stbd	-10.89	1,026.69	0.079	0.689	0.000	
Eng Rm Stbd	-9.02	1,026.69	0.000	0.000	0.000	
All Peak	-5.68	1,026.69	0.730	16.462	0.000	

The contents within the ballast tanks can be adjusted by the instructor via the 'Ballast Tanks' instructor display. The instructor is able to change the following:

- Liquid density within the tank
- Liquid level (% full)

To change either of the above the model has to be in the 'Freeze' mode. The new values can be entered and when the model is next placed into the 'Run' mode the tank contents will update accordingly.

Using the above the instructor can adjust the tank levels to suit the required draft and trim for the proposed exercise situation.

Fuel & FW Tanks

FUEL & FRESH WATER TANKS			
Heavy Fuel Oil	Density	Liquid level (%)	Fill/Empty (m³/min)
No.1 (P)	990.0	0.980	0.000
No.2 (S)	990.0	0.980	0.000
HFO Sett (P)	990.0	0.980	0.000
HFO Sett (S)	990.0	0.980	0.000
HFO Service (P)	990.0	0.980	0.000
HFO Service (S)	990.0	0.980	0.000
Fresh Water	Density	Liquid level (%)	Fill/Empty (m³/min)
Distilled Water Port	1,000.0	1.000	0.000
Distilled Water Stbd	1,000.0	1.000	0.000
Fresh Water Port	1,000.0	1.000	0.000
Fresh Water Stbd	1,000.0	1.000	0.000
Diesel Oil	Density	Liquid level (%)	Fill/Empty (m³/min)
Diesel Oil Service (P)	900.0	0.980	0.000
Diesel Oil Service (S)	900.0	0.980	0.000

To ensure the draughts and stability for the vessel are calculated and displayed correctly, the fuel and fresh water tanks need to have appropriate contents for the condition being simulated. The Fuel & FW tank instructor display allows the instructor to input and change the contents of the tanks as required. For each of the tanks the instructor may change:

- Liquid density within the tank
- Liquid level (% full)

To change either of the above the model has to be in the 'Freeze' mode. The new values can be entered and when the model is next placed into the 'Run' mode the tank contents and stability criteria will update accordingly.

The facility is also provided to allow the simulation of the tanks being filled or emptied as part of the simulation (ie bunkering operations in progress) by defining the filling /emptying rate for that tank in m³/min

- To fill a tank
Enter a positive number (ie > 0.000) into the 'Fill/Empty' column (100m³/hr = enter 1.667/min)
- To empty a tank
Enter a negative number (ie < 0.000) into the 'Fill/Empty' column (-100m³/hr = enter -1.667/min)

Alarms

The following is a list of the alarms that exist within the LNG Carrier models, together with their respective ID #.

Alarm ID	Description
31066	LO Level Tk.1
31067	LO Level Tk.2
31068	LO Level Tk.3
31069	LO Level Tk.4
31070	HI Level Tk.1
31071	HI Level Tk.2
31072	HI Level Tk.3
31073	HI Level Tk.4
31074	HIHI Level Tk.1
31075	HIHI Level Tk.2
31076	HIHI Level Tk.3
31077	HIHI Level Tk.4
31078	VHI Level Tk.1
31079	VHI Level Tk.2
31080	VHI Level Tk.3
31081	VHI Level Tk.4
31082	HIHI Pres Tk.1 (P >22 kPa)
31083	HIHI Pres Tk.2
31084	HIHI Pres Tk.3
31085	HIHI Pres Tk.4
31086	EHI Pres Tk.1.(P >25 Kpa
31087	EHI Pres Tk.2
31088	EHI Pres Tk.3
31089	EHI Pres Tk.4
31090	LO Pres Tk.1
31091	LO Pres Tk.2
31092	LO Pres Tk.3
31093	LO Pres Tk.4
31094	LOLO Pres Tk.1
31095	LOLO Pres Tk.2
31096	LOLO Pres Tk.3
31097	LOLO Pres Tk.4
31098	CTS Failure Tk.1
31099	CTS Failure Tk.2
31100	CTS Failure Tk.3
31101	CTS Failure Tk.4
31102	LO Tnk.1 Bottom Aft Centre IBS
31103	LO Tnk.2 Bottom Aft Centre IBS
31104	LO Tnk.3 Bottom Aft Centre IBS

31105	LO Tnk.4 Bottom Aft Centre IBS
31106	LO Tnk.1 Bottom Centre IBS T
31107	LO Tnk.2 Bottom Centre IBS T
31108	LO Tnk.3 Bottom Centre IBS T
31109	LO Tnk.4 Bottom Centre IBS T
31110	LO Tnk.1 Port Lower IBS T
31111	LO Tnk.2 Port Lower IBS T
31112	LO Tnk.3 Port Lower IBS T
31113	LO Tnk.4 Port Lower IBS T
31114	LO Tnk.1 Stbd Lower IBS T
31115	LO Tnk.2 Stbd Lower IBS T
31116	LO Tnk.3 Stbd Lower IBS T
31117	LO Tnk.4 Stbd Lower IBS T
31118	LO Tnk.1 Port Mid IBS T
31119	LO Tnk.2 Port Mid IBS T
31120	LO Tnk.3 Port Mid IBS T
31121	LO Tnk.4 Port Mid IBS T
31122	LO Tnk.1 Stbd Mid IBS T
31123	LO Tnk.2 Stbd Mid IBS T
31124	LO Tnk.3 Stbd Mid IBS T
31125	LO Tnk.4 Stbd Mid IBS T
31126	LO Tnk.1 Port Upper IBS T
31127	LO Tnk.2 Port Upper IBS T
31128	LO Tnk.3 Port Upper IBS T
31129	LO Tnk.4 Port Upper IBS T
31130	LO Tnk.1 Stbd Upper IBS T
31131	LO Tnk.2 Stbd Upper IBS T
31132	LO Tnk.3 Stbd Upper IBS T
31133	LO Tnk.4 Stbd Upper IBS T
31134	LO Tnk.1 Top Centre IBS T
31135	LO Tnk.2 Top Centre IBS T
31136	LO Tnk.3 Top Centre IBS T
31137	LO Tnk.4 Top Centre IBS T
31138	LO Tnk.1 Bottom Aft Centre IS
31139	LO Tnk.2 Bottom Aft Centre IS
31140	LO Tnk.3 Bottom Aft Centre IS
31141	LO Tnk.4 Bottom Aft Centre IS
31142	LO Tnk.1 Bottom Centre IS T
31143	LO Tnk.2 Bottom Centre IS T
31144	LO Tnk.3 Bottom Centre IS T

31145	LO Tnk.4 Bottom Centre IS T
31146	LO Tnk.1 Fwd Centre IS T
31147	LO Tnk.2 Fwd Centre IS T
31148	LO Tnk.3 Fwd Centre IS T
31149	LO Tnk.4 Fwd Centre IS T
31150	LO Tnk.1 Top Centre IS T
31151	LO Tnk.2 Top Centre IS T
31152	LO Tnk.3 Top Centre IS T
31153	LO Tnk.4 Top Centre IS T
31154	LO Tnk.1 Top Fwd IS T
31155	LO Tnk.2 Top Fwd IS T
31156	LO Tnk.3 Top Fwd IS T
31157	LO Tnk.4 Top Fwd IS T
31158	LO Tnk No.1 Fwd Top Rt Bhd T
31159	LO Tnk No.2 Fwd Top Rt Bhd T
31160	LO Tnk No.3 Fwd Top Rt Bhd T
31161	LO Tnk No.4 Fwd Top Rt Bhd T
31162	LO Tnk No.1 Fwd Top Lt Bhd T
31163	LO Tnk No.2 Fwd Top Lt Bhd T
31164	LO Tnk No.3 Fwd Top Lt Bhd T
31165	LO Tnk No.4 Fwd Top Lt Bhd T
31166	LO Tnk No.1 Fwd Bot Lt Bhd T
31167	LO Tnk No.2 Fwd Bot Lt Bhd T
31168	LO Tnk No.3 Fwd Bot Lt Bhd T
31169	LO Tnk No.4 Fwd Bot Lt Bhd T
31170	LO Tnk No.1 Fwd Bot Rt Bhd T
31171	LO Tnk No.2 Fwd Bot Rt Bhd T
31172	LO Tnk No.3 Fwd Bot Rt Bhd T
31173	LO Tnk No.4 Fwd Bot Rt Bhd T
31174	LO Tnk No.1 Fwd Bot Rt Bhd T
31175	LO Tnk No.2 Fwd Bot Rt Bhd T
31176	LO Tnk No.3 Fwd Bot Rt Bhd T
31177	LO Tnk No.4 Fwd Bot Rt Bhd T
31178	LO Tnk No.1 Aft Top Rt Bhd T
31179	LO Tnk No.2 Aft Top Rt Bhd T
31180	LO Tnk No.3 Aft Top Rt Bhd T
31181	LO Tnk No.4 Aft Top Rt Bhd T
31182	LO Tnk No.1 Aft Top Lt Bhd T
31183	LO Tnk No.2 Aft Top Lt Bhd T
31184	LO Tnk No.3 Aft Top Lt Bhd T
31185	LO Tnk No.4 Aft Top Lt Bhd T
31186	LO Tnk No.1 Aft Bot Lt Bhd T
31187	LO Tnk No.2 Aft Bot Lt Bhd T
31188	LO Tnk No.3 Aft Bot Lt Bhd T

31189	LO Tnk No.4 Aft Bot Lt Bhd T
31190	LO Tnk No.1 Aft Bot Rt Bhd T
31191	LO Tnk No.2 Aft Bot Rt Bhd T
31192	LO Tnk No.3 Aft Bot Rt Bhd T
31193	LO Tnk No.4 Aft Bot Rt Bhd T
31194	LO Tnk No.1 Aft Bot Rt Bhd T
31195	LO Tnk No.2 Aft Bot Rt Bhd T
31196	LO Tnk No.3 Aft Bot Rt Bhd T
31197	LO Tnk No.4 Aft Bot Rt Bhd T
31198	LO Press IBS 1
31199	LO Press IBS 2
31200	LO Press IBS 3
31201	LO Press IBS 4
31202	LO Press IS 1
31203	LO Press IS 2
31204	LO Press IS 3
31205	LO Press IS 4
31206	LO Press IS/IBS 1
31207	LO Press IS/IBS 2
31208	LO Press IS/IBS 3
31209	LO Press IS/IBS 4
31210	HI Press IBS 1
31211	HI Press IBS 2
31212	HI Press IBS 3
31213	HI Press IBS 4
31214	HI Press IS 1
31215	HI Press IS 2
31216	HI Press IS 3
31217	HI Press IS 4
31218	HI Press IS/IBS 1
31219	HI Press IS/IBS 2
31220	HI Press IS/IBS 3
31221	HI Press IS/IBS 4
31222	No.1 Tk. Filling Valve stuck
31223	No.2 Tk. Filling Valve stuck
31224	No.3 Tk. Filling Valve stuck
31225	No.4 Tk. Filling Valve stuck
31226	HI Vapour Header Pres
31227	LO 1/P Crg.Pmp Amps
31228	LO 2/P Crg.Pmp Amps
31229	LO 3/P Crg.Pmp Amps
31230	LO 4/P Crg.Pmp Amps
31231	LO 1/S Crg.Pmp Amps
31232	LO 2/S Crg.Pmp Amps

31233	LO 3/S Crg.Pmp Amps
31234	LO 4/S Crg.Pmp Amps
31235	LOLO 1/P Crg.Pmp Amps
31236	LOLO 2/P Crg.Pmp Amps
31237	LOLO 3/P Crg.Pmp Amps
31238	LOLO 4/P Crg.Pmp Amps
31239	LOLO 1/S Crg.Pmp Amps
31240	LOLO 2/S Crg.Pmp Amps
31241	LOLO 3/S Crg.Pmp Amps
31242	LOLO 4/S Crg.Pmp Amps
31243	HI 1/P Crg.Pmp Amps
31244	HI 2/P Crg.Pmp Amps
31245	HI 3/P Crg.Pmp Amps
31246	HI 4/P Crg.Pmp Amps
31247	HI 1/S Crg.Pmp Amps
31248	HI 2/S Crg.Pmp Amps
31249	HI 3/S Crg.Pmp Amps
31250	HI 4/S Crg.Pmp Amps
31251	HIHI 1/P Crg.Pmp Amps
31252	HIHI 2/P Crg.Pmp Amps
31253	HIHI 3/P Crg.Pmp Amps
31254	HIHI 4/P Crg.Pmp Amps
31255	HIHI 1/S Crg.Pmp Amps
31256	HIHI 2/S Crg.Pmp Amps
31257	HIHI 3/S Crg.Pmp Amps
31258	HIHI 4/S Crg.Pmp Amps
31259	LO 1/P Crg.Pmp Disch. P
31260	LO 2/P Crg.Pmp Disch. P
31261	LO 3/P Crg.Pmp Disch. P
31262	LO 4/P Crg.Pmp Disch. P
31263	LO 1/S Crg.Pmp Disch. P
31264	LO 2/S Crg.Pmp Disch. P
31265	LO 3/S Crg.Pmp Disch. P
31266	LO 4/S Crg.Pmp Disch. P
31267	1/P Crg.Pmp Disch. Valve stuck
31268	2/P Crg.Pmp Disch. Valve stuck
31269	3/P Crg.Pmp Disch. Valve stuck
31270	4/P Crg.Pmp Disch. Valve stuck
31271	1/S Crg.Pmp Disch. Valve stuck
31272	2/S Crg.Pmp Disch. Valve stuck
31273	3/S Crg.Pmp Disch. Valve stuck
31274	4/S Crg.Pmp Disch. Valve stuck
31275	LO No.1 Spray Pmp Amps
31276	LO No.2 Spray Pmp Amps

31277	LO No.3 Spray Pmp Amps
31278	LO No.4 Spray Pmp Amps
31279	LOLO No.1 Spray Pmp Amps
31280	LOLO No.2 Spray Pmp Amps
31281	LOLO No.3 Spray Pmp Amps
31282	LOLO No.4 Spray Pmp Amps
31283	HI No.1 Spray Pmp Amps
31284	HI No.2 Spray Pmp Amps
31285	HI No.3 Spray Pmp Amps
31286	HI No.4 Spray Pmp Amps
31287	HIHI No.1 Spray Pmp Amps
31288	HIHI No.2 Spray Pmp Amps
31289	HIHI No.3 Spray Pmp Amps
31290	HIHI No.4 Spray Pmp Amps
31291	LO Vapour Header Pres
31292	LO No.2 Glycol Return T
31293	LO No.1 Glycol Return T
31294	LO No.2 Glycol Pmp BackP
31295	LO No.1 Glycol Pmp BackP
31296	LO No.2 Steam/Glycol Diff.P
31297	LO No.1 Steam/Glycol Diff.P
31298	LO No.2 Steam P
31299	LO No.1 Steam P
31300	HI No.2 Steam P
31301	HI No.1 Steam P
31302	HI No.2 Heater Outlet T
31303	HI No.1 Heater Outlet T
31304	HiHi No.2 Heater Outlet T(>105 C)
31305	HiHi No.1 Heater Outlet T(>105 C)
31306	Gas Detection Group Alarm
31307	LOLO H/D Comp.1 L.O. P
31308	LOLO H/D Comp.2 L.O. P
31309	HIHI H/D Comp.1 L.O. T
31310	HIHI H/D Comp.2 L.O. T
31311	LO H/D Comp.1 L.O. T
31312	LO H/D Comp.2 L.O. T
31313	HI H/D Comp.1 Bearing T
31314	HI H/D Comp.2 Bearing T
31315	HIHI H/D Comp.1 Bearing T
31316	HIHI H/D Comp.2 Bearing T
31317	H/D Comp.1 Rotor Excess Vibr.
31318	H/D Comp.2 Rotor Excess Vibr.
31319	H/D Comp.1 Rotor Axis Excess P
31320	H/D Comp.2 Rotor Axis Excess P

31321	H/D: Comp.1 N2 Seal Gas P --LO
31322	H/D: Comp.2 N2 Seal Gas P --LO
31323	H/D: Comp.1 N2 Seal Gas P --LOLO
31324	H/D: Comp.2 N2 Seal Gas P --LOLO
31325	LO H/D Comp.1 Bulkhead Seal P
31326	LO H/D Comp.2 Bulkhead Seal P
31327	LOLO H/D Comp.1 Bulkhead Seal
31328	LOLO H/D Comp.2 Bulkhead Seal
31329	HI H/D Comp.1 Bulkhead Seal T
31330	HI H/D Comp.2 Bulkhead Seal T
31331	HIHI H/D Comp.1 Bulkhead Seal T
31332	HIHI H/D Comp.2 Bulkhead Seal T
31333	HI H/D Comp.1 Disch. T
31334	HI H/D Comp.2 Disch. T
31335	HIHI H/D Comp.1 Disch. T
31336	HIHI H/D Comp.2 Disch. T
31337	LOLO L/D Comp.1 L.O. P
31338	LOLO L/D Comp.2 L.O. P
31339	HIHI L/D Comp.1 L.O. T
31340	HIHI L/D Comp.2 L.O. T
31341	LO L/D Comp.1 L.O. T
31342	LO L/D Comp.2 L.O. T
31343	HI L/D Comp.1 Bearing T
31344	HI L/D Comp.2 Bearing T
31345	HIHI L/D Comp.1 Bearing T
31346	HIHI L/D Comp.2 Bearing T
31347	L/D Comp.1 Rotor Excess Vibr.
31348	L/D Comp.2 Rotor Excess Vibr.
31349	L/D Comp.1 Rotor Axis Excess P
31350	L/D Comp.2 Rotor Axis Excess P
31351	LO L/D Comp.1 N2 Seal Gas P
31352	LO L/D Comp.2 N2 Seal Gas P
31353	LOLO L/D Comp.1 N2 Seal Gas P
31354	LOLO L/D Comp.2 N2 Seal Gas P
31355	LO L/D Comp.1 Bulkhead Seal P
31356	LO L/D Comp.2 Bulkhead Seal P
31357	LOLO L/D Comp.1 Bulkhead Seal
31358	LOLO L/D Comp.2 Bulkhead Seal
31359	HI L/D Comp.1 Bulkhead Seal T
31360	HI L/D Comp.2 Bulkhead Seal T
31361	HIHI L/D Comp.1 Bulkhead Seal
31362	HIHI L/D Comp.2 Bulkhead Seal
31363	HI L/D Comp.1 Disch. T
31364	HI L/D Comp.2 Disch. T

31365	HIHI L/D Comp.1 Disch. T
31366	HIHI L/D Comp.2 Disch. T
31367	LO No.2 Heater Disch. T
31368	LO No.1 Heater Disch. T
31369	HI No.2 Heater Disch. T
31370	HI No.1 Heater Disch. T
31371	HIHI No.2 Heater Disch. T
31372	HIHI No.1 Heater Disch. T
31373	HI No.2 Heater Condensate Leve
31374	HI No.1 Heater Condensate Leve
31375	LO No.2 Heater Condensate T
31376	LO No.1 Heater Condensate T
31377	LOLO No.2 Heater Condensate T
31378	LOLO No.1 Heater Condensate T
31379	LO LNG Vapouriser Disch. T
31380	LO Forcing Vapouriser Disch. T
31381	HI LNG Vapouriser Disch. T
31382	HI Forcing Vapouriser Disch. T
31383	HI LNG Vapouriser Condensate L
31384	HI Forcing Vapouriser Condensa
31385	LO Forcing Vapouriser Mist Sep
31386	LO BOG line P
31387	LO Seal Water P
31388	HI IG O2 content
31389	HIHI IG O2 content
31390	LO IG O2 content
31391	HI IG Delivery P
31392	HIHI IG Delivery P
31393	HI IG dew-point
31394	HI N2 O2 content
31395	HIHI N2 O2 content
31396	HI N2 dew-point
31397	LO N2 Buffer Tank P
31398	HI N2 Buffer Tank P
31399	HI IBS/IS Pressurisation Line
31400	LO IBS/IS Pressurisation Line
31401	LO Sample Flow (Fail)
31402	HI % LEL Cargo Mach.Room (1)
31403	HI % LEL Cargo Mach.Room (2)
31404	HI % LEL Cargo Mach.Motor Room
31405	HI % LEL Cargo Mach.Motor Room
31406	HI % LEL Fuel Gas Main Pipe Du
31407	HI % LEL Fuel Gas Main Pipe Du
31408	HI % LEL Fuel Gas Main Pipe Du

31409	HI % LEL Boiler Hood
31410	HI % LEL IG Line after Drier
31411	HI % LEL ESCR
31412	HI % No.1 IBS (1)
31413	HI % LEL No.1 IBS (2)
31414	HI % LEL No.1 IS
31415	HI % LEL No.2 IBS (1)
31416	HI % LEL No.2 IBS (2)
31417	HI % LEL No.2 IS
31418	HI % LEL No.3 IBS (1)
31419	HI % LEL No.3 IBS (2)
31420	HI % LEL No.3 IS
31421	HI % LEL No.4 IBS (1)
31422	HI % LEL No.4 IBS (2)
31423	HI % LEL No.4 IS
31424	HI % LEL No.1 Cofferdam
31425	HI % LEL No.2 Cofferdam
31426	HI % LEL No.3 Cofferdam
31427	HI % LEL No.4 Cofferdam
31428	HI % LEL No.5 Cofferdam
31429	HI % LEL Duct Keel (1)
31430	HI % LEL Duct Keel (2)
31431	HI % LEL Gas Vent Drain Tnk
31432	HI % LEL Bosun Store
31433	HI % LEL Fwd Pump Room
31434	HI % LEL Bow Thruster Room
31435	HI % LEL Underdeck Passage (Fw
31436	HI % LEL Underdeck Passage (Af
31437	HI % LEL Underdeck Passage (Fw
31438	HI % LEL Underdeck Passage (Af
31439	HI % LEL No.1 Vent Disch
31440	HI % LEL No.2 Vent Disch
31441	HI % LEL No.3 Vent Disch
31442	HI % LEL No.4 Vent Disch
31443	LO Level Forepeak WB
31444	LO Fwd P WB Tank P
31445	LO Fwd S WB Tank P
31446	LO No.1 P WB Tank P
31447	LO No.1 S WB Tank P
31448	LO No.2 P Fwd WB Tank P
31449	LO No.2 S Fwd WB Tank P
31450	LO No.2 P Aft WB Tank P
31451	LO No.2 S Aft WB Tank P
31452	LO No.3 P Fwd WB Tank P

31453	LO No.3 S Fwd WB Tank P
31454	LO No.3 P Aft WB Tank P
31455	LO No.3 S Aft WB Tank P
31456	LO No.4 P WB Tank P
31457	LO No.4 S WB Tank P
31458	LO E/R P WB Tank P
31459	LO E/R S WB Tank P
31460	LO Aft Peak WB Tank P
31461	HI Level Forepeak WB
31462	HI Fwd P WB Tank P
31463	HI Fwd S WB Tank P
31464	HI No.1 P WB Tank P
31465	HI No.1 S WB Tank P
31466	HI No.2 P Fwd WB Tank P
31467	HI No.2 S Fwd WB Tank P
31468	HI No.2 P Aft WB Tank P
31469	HI No.2 S Aft WB Tank P
31470	HI No.3 P Fwd WB Tank P
31471	HI No.3 S Fwd WB Tank P
31472	HI No.3 P Aft WB Tank P
31473	HI No.3 S Aft WB Tank P
31474	HI No.4 P WB Tank P
31475	HI No.4 S WB Tank P
31476	HI E/R P WB Tank P
31477	HI E/R S WB Tank P
31478	HI Aft Peak WB Tank P
31479	HI Eductor Suct. P
31480	HI Fuse T (Fire)
31481	LO Hydraulic P
31482	LO Control Air P
31483	P.1 Burst Pipe Setp
31484	P.2 Burst Pipe Setp
31485	P.3 Burst Pipe Setp
31486	P.4 Burst Pipe Setp
31487	S.1 Burst Pipe Setp
31488	S.2 Burst Pipe Setp
31489	S.3 Burst Pipe Setp
31490	S.4 Burst Pipe Setp
31491	No.1 Spray Pmp Disch. Valve st
31492	No.2 Spray Pmp Disch. Valve st
31493	No.3 Spray Pmp Disch. Valve st
31494	No.4 Spray Pmp Disch. Valve st
31495	No.1 Spray Return Valve stuck
31496	No.2 Spray Return Valve stuck

31497	No.3 Spray Return Valve stuck
31498	No.4 Spray Return Valve stuck
31499	HI Mooring Load
31500	Min Flow flagged if shut again
31501	LOLO BOG Supply P
31502	HIHI % LEL Cargo Mach.Room (1)
31503	HIHI % LEL Cargo Mach.Room (2)
31504	HIHI % LEL Cargo Mach.Motor Ro
31505	HIHI % LEL Cargo Mach.Motor Ro
31506	HIHI % LEL Fuel Gas Main Pipe
31507	HIHI % LEL Fuel Gas Main Pipe
31508	HIHI % LEL Fuel Gas Main Pipe
31509	HIHI % LEL Boiler Hood
31510	HIHI % LEL IG Line after Drier
31511	HIHI % LEL ESCR
31512	LO H/D Comp.1 L.O. P
31513	LO H/D Comp.2 L.O. P
31514	HIHI H/D Comp.1 L.O. T
31515	HIHI H/D Comp.2 L.O. T
31516	LO L/D Comp.1 L.O. P
31517	LO L/D Comp.2 L.O. P
31518	HI L/D Comp.1 L.O. T
31519	HI L/D Comp.2 L.O. T
31520	LOLO LNG Vapouriser Disch. T --MC
31521	LOLO Forcing Vapouriser Disch. --MC
31522	LOLO Level Tk.1 --MC
31523	LOLO Level Tk.2 --MC
31524	LOLO Level Tk.3 --MC
31525	LOLO Level Tk.4 --MC
31526	VHI Pres Tk.1(P>23 kPa)
31527	VHI Pres Tk.2
31528	VHI Pres Tk.3
31529	VHI Pres Tk.4
31530	HI Pres Tk.1(P>20 kPa)
31531	HI Pres Tk.2
31532	HI Pres Tk.3
31533	HI Pres Tk.4
31534	LOLO Press Tk.1 (P<2 kPa)
31535	LOLO Press Tk.2 (P<2 kPa)
31536	LOLO Press Tk.3 (P<2 kPa)
31537	LOLO Press Tk.4 (P<2 kPa)
31538	LOLO Vap Header Press (P<2 kPa)
31539	GCU Trip Indicator (Tk.1 P<4 kPa)
31540	GCU Stop Indicator (Tk.2 P<4 kPa)

31541	GCU Stop Indicator (Tk.3 P<4 kPa)
31542	GCU Stop Indicator (Tk.4 P<4 kPa)
31543	LO LO Tank Press diff Tank/IBS1 (<0.5 kPa)
31544	LO LO Tank Press diff Tank/IBS2 (<0.5 kPa)
31545	LO LO Tank Press diff Tank/IBS3 (<0.5 kPa)
31546	LO LO Tank Press diff Tank/IBS4 (<0.5 kPa)
31547	VLO Vap. Header Pressure(<0.3)
31548	SP for High Vapour header Pressure(>0.92*SP)
31549	BOG Compr.1 Suction P -HiHi
31550	BOG Compr.2 Suction P -HiHi
31551	BOG Compr.1 Suction P -Hi
31552	BOG Compr.2 Suction P -Hi
31553	BOG Compr.1 Suction P -LoLo
31554	BOG Compr.2 Suction P -LoLo
31555	BOG Compr.1 Suction T -HiHi
31556	BOG Compr.2 Suction T -HiHi
31557	BOG Compr.1 Suction T -Hi
31558	BOG Compr.2 Suction T -Hi
31559	BOG Compr.1 Diff P at Stage1 -Hi
31560	BOG Compr.2 Diff P at Stage1 -Hi
31561	BOG Compr.1 Interstage T -Hi
31562	BOG Compr.2 Interstage T -Hi
31563	BOG Compr.1 Interstage T -HiHi
31564	BOG Compr.2 Interstage T -HiHi
31565	BOG Compr.1 Discharge P -Hi
31566	BOG Compr.2 Discharge P -Hi
31567	BOG Compr.1 Discharge P -HiHi
31568	BOG Compr.2 Discharge P -HiHi
31569	BOG Compr.1 Discharge T -Hi
31570	BOG Compr.2 Discharge T -Hi
31571	BOG Compr.1 Discharge T -HiHi
31572	BOG Compr.2 Discharge T -HiHi
31573	BOG Compr.1 Bearing T-HiHi
31574	BOG Compr.2 Bearing T-HiHi
31575	BOG Compr.1 Bearing Vibr.-HiHi
31576	BOG Compr.2 Bearing Vibr.-HiHi
31577	BOG Compr.1 Shaft Displacement-HiHi
31578	BOG Compr.2 Shaft Displacement-HiHi
31579	BOG Compr.1 N2 Seal Gas P -LoLo
31580	BOG Compr.1 N2 Seal Gas P -LoLo


31581	BOG Compr.1 Bulkhead Seal P-LoLo
31582	BOG Compr.2 Bulkhead Seal P-LoLo
31583	BOG Compr.1 Bulkhead Seal T -HiHi
31584	BOG Compr.2 Bulkhead Seal T -HiHi
31585	BOG Compr.1 L.O. P-LoLo
31586	BOG Compr.2 L.O. P-LoLo
31587	BOG Compr.1 L.O. T -HiHi
31588	BOG Compr.2 L.O. T -HiHi

31589	BOG Compr.1 L.O. T -Hi
31590	BOG Compr.2 L.O. T -Hi
31591	After Cooler/Heater Outlet T-Lo
31592	Separaror Level-Hi
31593	Separaror Level-HiHi [483]
31594	DFDE: Low Methane Number at Separator Exit

Listing of Graphics Displays

Process Overview

Status



This provides the operator with access to the overall status of the vessel at any time including the following:

- Manifold Status – Provides indication of the position status of the manifold valves and the current flow rates on each manifold
- Cargo and Ballast Tank Status – The level within each tank is displayed, (Blue for Liquid Cargo, Green for ballast). The level indicators update automatically as the appropriate tanks are filled or emptied.
- Draught Information – Draughts fwd, aft and amidships are displayed. The amount of list is indicated in degrees with the red or green light indicating if list is to port or stbd.
- Machinery Room Ventilation Controls – If the fans for the cargo machinery room are not operating, or are stopped, the ESDS will be activated
- Weather Status
- Emergency Shutdown System Activation.


Hot links are located as follows:

- Manifold – links to manifold display
- Cargo tanks – link to the appropriate cargo tank display
- Ballast – links to ballast system display

Model parameters or malfunctions that can be accessed directly via the Status display include:

- Speed
- Flow control
- Weather conditions


Emergency Shutdown



Provides access to the controls related to the Emergency Shutdown System including:

- Selection of shore connection
- Indication of activation cause
- Tank Protection System (TPS) trigger override for Very high cargo tank level
- ESD trigger override for Extreme high cargo tank level
- Manual ESD activation point

Operation Mimics



A number of displays based on the main cargo pipeline display but adapted so that only the pipelines and equipment that will be used to undertake the operation concerned are displayed.

The relevant displays include:

- Inerting
- Cooldown
- Loading
- Discharge
- Warm Up
- Air Purge


Hot links are located as follows:

- Cargo tanks
- Vaporisers
- LD & HD Compressors
- Heaters
- Manifold

Model parameters or malfunctions that can be accessed directly via these displays include:

- Valve malfunctions
- Tank level malfunctions

Fixed Gas Detection




The automatic gas detector enables samples to be taken automatically on a sequential basis from all the defined points every 30 minutes (all samples have to be sampled at least once within that time period), or by the operator manually selecting specific points.

The operation of the system is described in the '[Fixed Gas Detection System](#)' section earlier in this document.

Model parameters or malfunctions that can be accessed directly via this display include:

- Alarm settings
- Gas Malfunctions in non-cargo spaces

Portable Gas Detection



The operator is provided with three portable gas instruments which may be operated manually. When any of the three instruments is operated the CO₂ and dewpoint readings for the space selected are provided automatically.

Located beneath the instruments are the sample points that may be monitored:

- Manifolds
- Main headers, fore & aft
- Spray headers on each tank
- Vent masts on each tank
- Cargo tank contents
- IBS & IS spaces
- Emergency pump column (EPT, EPB)
- Equipment


Full details of the instruments and their operation can be found in the [Portable Gas Detection](#) section earlier in this document.

Model parameters or malfunctions that can be accessed directly via this display include:

- Instrument malfunctions to introduce an error into the readings displayed

Cargo Pipelines

Cargo Pipelines



Provides overview of main pipelines associated with liquid and vapour on deck. Information is also provided on:

- Spray header pressure and temperature for all tanks
- Liquid header pressure and temperature
- Vapour header pressure and temperature
- Cargo tank information
- Manual ESD activation


Hot links are located as follows:

- Cargo tanks
- Vaporisers
- LD & HD Compressors
- Heaters
- Manifold

Model parameters or malfunctions that can be accessed directly via these displays include:

- Valve malfunctions
- Tank level malfunctions

Manifold



This display provides access to the manifold connections for all liquid and vapour lines.

Each manifold is provided with the control to allow the line to be blanked or connected to the shore. The appropriate status is applied when the indicator is illuminated

For each manifold there are three options:

- Blank off, arm not connected – in this position the manifold is open to the atmosphere so if the valves are opened and contents will flow into the atmosphere. Used during inerting and gas freeing
- Blank on, arm not connected – line is blanked so no flow
- Blank off, arm connected – line is connected to the shore

Above screen shot show the port lines connected to the shore arms, and stbd lines blanked and not connected.


Hot links are located as follows:

- HD Compressors
- N2 Supply

Model parameters or malfunctions that can be accessed directly via these displays include:

- Required flow rate for each liquid manifold (accessed by right clicking on external pressure display for the particular manifold)
- Valve malfunctions

Machinery Room



Provides overview of pipelines and connections between the various items of machinery and the main deck. The layout of the machinery room will change to reflect the different propulsion system selected for the model arrangement to be used (the above shows the arrangement for the 2 stage DFDE).

Controls are also shown for the machinery room ventilation.

Hot links are located as follows:


- GCU (Engine Room)
- IG Generator
- Cargo pipelines

Model parameters or malfunctions that can be accessed directly via these displays include:

- Valve malfunctions

Cargo Tanks

Cargo Tank No.1 (2,3,4)



Provides the pipeline arrangement within each of the cargo tanks together with the cargo, spray and emergency pump controls depending on the display selected. Details regarding the operation of the controls can be found earlier in this document in the following sections:

[Cargo Pumps](#)

[Spray Pumps](#)

Additional information displayed includes:

- Cargo tank alarms
- Sounding, volume and % full information
- Cargo tank pressure and temperatures


Hot links are located as follows:

- Cargo Pipelines

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Level malfunctions
- Valve Malfunctions
- Alarm settings and malfunctions

Temperature No.1 (2,3 4)



These displays show the temperature monitoring points within the Interbarrier and Insulation spaces surrounding the appropriate cargo tank. The displays are arranged on the basis that the operator is standing within the cargo tank at the centre and then looking at the respective bulkhead.

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Alarm settings and malfunctions

Glycol System



The controls, equipment and pipeline arrangements for the Glycol Heating System. Both heaters are supplied from the 'Steam Supply' and the pumps are operated using the standard 'Combined Logical Controllers' as described in the G-Sim Operations Manual (above shows No.1 pump stopped, and No.2 pump in operation).


The coils within the cofferdams are supplied via three way valves which are automatic in operation so the position cannot be set by the operator.

Note: all the outlet return valves from the three way valves need to be open to allow full circulation when the three way valve inlet to the cofferdam coil is closed.

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

HD Compressors



Provides access to all the controls and information related to the High Duty (H/D) Compressors. Details about the operation of the various items of machinery or equipment can be found in the [HD Compressor](#) section earlier in this document.


Hot links are located as follows:

- Heaters
- Manifold
- Cargo pipelines
- Lub oil system
- N2 System

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Level malfunctions
- Valve Malfunctions
- Alarm settings and malfunctions

LD Compressors



Provides access to all the controls and information related to the Low Duty (L/D) Compressors. The controls displayed will change dependent of the propulsion system that has been selected. The above shows the arrangement for the 2 stage DFDE.

Details about the operation of the various items of machinery or equipment can be found in the [LD Compressor](#) section earlier in this document.


Hot links are located as follows:

- Heaters
- Vaporisers
- Cargo pipelines
- Lub oil system
- N2 System

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Level malfunctions
- Valve Malfunctions
- Alarm settings and malfunctions

Lub Oil System



The controls and equipment comprising the lubricating oil system for the compressors. The pumps are operated using a simple logical controller.

The lub oil FW cooler bypass valve is automatically controlled. This also applies to the steam supply valve to the Sump Heater. The operator is not able to set the position of these two valves.


Hot links are located as follows:

- HD Compressors
- LD Compressors
- Steam system

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

Heaters



Provides access to all the controls and information related to the heaters. Details of the operation of the various items of equipment can be found in the [Cargo Heaters](#) section earlier in this document. The controls displayed will change dependent of the propulsion system that has been selected.


Hot links are located as follows:

- HD Compressors
- LD Compressors
- Steam system
- Cargo pipelines

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

LNG Vaporiser



Provides access to all the controls and information related to the LNG Vaporisers. Details about the operation of the vaporiser can be found in the [Vaporisers](#) section earlier in this document.


Hot links are located as follows:

- Forcing Vaporiser
- Mist Separator
- Steam system
- Cargo pipelines

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

Forcing Vaporiser



Provides access to all the controls and information related to the LNG Vaporisers. Details about the operation of the vaporiser can be found in the [Vaporisers](#) section earlier in this document. The arrangement displayed will be dependent upon the propulsion system selected.

Hot links are located as follows:

- LNG Vaporiser
- LD Compressors
- Steam system
- Cargo pipelines

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

[illegible]


Hot links are located as follows:

- Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- 84

Nitrogen

Nitrogen Generator



Controls and arrangement related to the Nitrogen generation and supply system. Details regarding the operation of the generators can be found in the [Nitrogen Generator](#) section earlier in this document.

Hot links are located as follows:

- Engine Room
- Machinery Room
- Cargo pipelines
- N2 pressurisation system

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions
- N2 properties
 - Oxygen & dewpoint settings
 - Delivery pressure
 - Delivery Temperature

Nitrogen Distribution



Controls and arrangement related to the Nitrogen supply system to the spaces surrounding the cargo tanks. The arrangement displayed will be dependent upon the cargo containment type selected for the model being used. The above shows the arrangement for the Mark III system. Details regarding the operation of the system can be found in the [Nitrogen Generator](#) section earlier in this document.

Hot links are located as follows:


- Engine Room
- Machinery Room
- Manifold
- N2 Generator

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

Inert Gas

Inert Gas



Controls and arrangement related to the Dry Air and Inert Gas generation and supply system. Details regarding the operation of the system can be found in the [IG Generator](#) section earlier in this document.

Water for the IG scrubber is supplied via the Ballast System

Hot links are located as follows:


- Machinery Room
- Cargo pipelines
- Ballast System

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions
- IG properties
 - Oxygen & dewpoint settings
 - Delivery pressure
 - Delivery Temperature

Engine Room

Engine Room



Controls and arrangement related to the supply of gas to the engine room for use in the propulsion system. The arrangement displayed will be dependent upon the propulsion system selected.

Hot links are located as follows:


- Machinery Room

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

Ballast

Ballast System



Provides access to all the controls and information relating to the ballast system. Depending upon the vessel arrangement selected the system comprises of either:

- Three electric, centrifugal pumps together with a small stripping eductor that is driven by water taken from the water spray pump. No. 3 pump is used to supply cooling water to the Inert Gas Generator when in required.
- Two electric, centrifugal ballast pumps, incorporating a vac-strip system, together with two stripping eductors.

Hot links are located as follows:

- IG Generator

Model parameters or malfunctions that can be accessed directly via the cargo tank displays include:

- Valve Malfunctions
- Alarm settings and malfunctions

Ancillary Tanks

This display shows the current status of the Fuel oil and Fresh water tanks within the model to the operator. The levels and contents of these tanks is controlled by the instructor via the appropriate instructor portal display. See section earlier in this document.